

Model: BATTERY LINE

Order number: 69-130667-030

Correct use: Storage of batteries



Classical door technology (door handle), door hinge right For the storage of lithium-ion batteries
 Type-tested by MPA/ TÜV SÜD according to DIN EN 14470-1, DIN EN 16121, DIN EN 16122, and DIN 31000 Loss prevention in terms of VdS 3103 Mark of approval: Safety tested and CE mark
 Construction and colour:

- Outer carcass sheet steel, RAL 7035
- Doors sheet steel, PANTONE 389 C
- Inner carcass decor panels, RAL 7035 Fittings and features:
- Doors remain open in any position
- Doors close automatically in case of fire
- Cylinder locks for access security
- Backdraftlock after inside fire
- bottom tray sheet steel, RAL 7035
- 3 storage levels sheet steel, RAL 7035
- 1 storage area per storage level
- exhaust air connection socket on the cabinet roof
- visual inspection of the ventilation opening
- earthing connection on the cabinet roof
- interior fittings grounded to carcass
- adjustable feet for level adjustment
- set-back base, RAL 7015 more technical information: www.dueperthal.com

Category:	Type 90 - lithium ion batteries
Model size	S
Model type	STANDARD (storage shelves)

Outer width [mm]:	594
Outer depth [mm]:	612
Outer height [mm]:	1.385
Net weight [kg]:	220,00
Supply voltage	no charging system
Equipment package	without signal transmission
Number of storage levels	3
Number of storage areas per storage level	1
Door operation	classical technology
Door technology	wing door technology